

# **UH239**

# UH239 Series Filters ULTIPLEAT® SRT HIGH PRESSURE FILTERS

Port Size 11/4" and 11/2"



# **UH239 Series Filters**

# HIGH PRESSURE FILTERS Technical Information

#### **Features**

- Patented Ultipleat (laid-over pleat) filter medium pack
- Coreless, cageless element configuration
- Pall Stress-Resistant Technology (SRT) Media
- In-to-out filter element flow path
- Flows to 350 L/min (92 US gpm)
- Pressures to 420 bar (6100 psi)
- Port size 1¼" and 1½"

# Notes and Specifications Filter Housing

- Maximum Working Pressure: 420 bar (6100 psi)
- Rated Fatigue Pressure:

   0-240 bar (0-3500 psi) per NFPA
   T2.06.01R2-2001 CAT C/90/\*
   (1 million cycles), verified by testing at 0-280 bar (0-4050 psi) for
   1 million cycles.

   Contact Pall for applications with higher pressures at lower cycles
- Typical Burst Pressure: 1500 bar (21,750 psi)
- Fluid Compatibility:
   Compatible with all petroleum oils, water glycols, water-oil emulsions and most synthetic hydraulic and lubrication fluids
- Temperature Range:
  Fluorocarbon Seals:
  -29 °C to 120 °C (-20 °F to 250 °F)
  60 °C (140 °F) maximum temperature
  in HWCF or water glycol fluids
- Bypass Valve Setting:
   4.5 bard (65 psid)
- Indicator Pressure Setting: 3.5 bard (50 psid)
- Materials of Construction:
   Head and Cover: Ductile Cast Iron
   Tube: Carbon steel

#### **Filter Element**


- Filter Element Burst Pressure: 10 bard (150 psid)
- Ultipleat SRT Element Construction: Inorganic fibers impregnated and bonded with epoxy resins. Polymer endcaps. Anti-static media

The equipment has been assessed in accordance with the guidelines laid down in The European Pressure Directive 97/23/EC and has been classified within Sound Engineering Practice S.E.P. Suitable for use with Group 2 fluids only. Consult Sales for other fluid gas group suitability.

#### **Pressure Drop Information**

#### Housing pressure drop using fluid with 0.9 S.G.

Housing pressure drop is directly proportional to specific gravity.



## **Element Pressure Drop**

Multiply actual flow rate times factor in table below to determine pressure drop with fluid at 32 cSt (150 SUS), 0.9 S.G. Correct for other fluids by multiplying new viscosity in cSt/32 (SUS/150) x new S.G./0.9. Note: factors are per 1000 L/min and per 1 US gpm.

## 219 Series Filter Elements — bard/1000 L/min (psid/US gpm)

Length Code	AZ	AP	AN	AS	AT
13	5.95 (0.327)	2.52 (0.139)	1.70 (0.093)	1.05 (0.058)	0.80 (0.044)
20	3.95 (0.217)	1.68 (0.092)	1.13 (0.062)	0.70 (0.038)	0.53 (0.029)

#### Sample $\Delta P$ calculation

UH239 Series 13" length housing with C24 (1½" BSP) threaded port using an UE219 filter element with AN grade media. Operating conditions 300 L/min flow rate using a hydraulic fluid of 50 cSt and specific gravity (S.G.) 1.2.

#### Total Filter AP

- $= \Delta P$  housing  $+ \Delta P$  element
- $= (0.4 \times 1.2/0.9)$  bard (housing)
- + ((300 x 1.70/1000) x 50/32 x 1.2/0.9) bard (element)
- = 0.53 bard (housing) + 1.06 bard (element)
- = 1.59 bard (23.1 psid)

# **UH239 Series Filters**

# **Ordering Information**

# For new installations, select one complete part number from each section below

## **Section 1**

# **Housing P/N:**

Note: Pall Ultipleat SRT filter housings are supplied without filter elements or warning devices fitted. Never operate the filter unless a filter element is fitted and all warning device ports are sealed.

# Seal Kit P/N:

**UH 239 C** 

Table 1 Table 2

ZG 1

Note: Z indicates fluorocarbon seals are standard. Other options are available; contact Pall. The suffix '1' at the end of the Housing P/N designates 1 indicator port fitted with a plug.

## **UH 239 SKZ**

\*Other seal material options are available; Contact Pall.

Table 1: Housing Port Options

Code	Port	Max. Operating Pressure
A20	11/4" SAE J1926 straight thread	
A24	1½" SAE J1926 straight thread	420 bar (6100 psi)
C20	11/4" BSP ISO 228 threads	420 bai (0100 psi)
C24	11/2" BSP ISO 228 threads	
E20	11/4" Flange J518C code 62 with 1/2"-13 UNC holding bolts	414 bar (3000 psi)
G20	11/4" ISO 6162 split flange with M12 x 1.75 holding bolts	400 bar (5800 psi)

Table 2: Filter Housing Length Options

Code	Length (in)*
13	13
20	20

<sup>\*</sup> Nominal length

## Section 2

## **Element P/N:**

**UE 219** 





Z

Note: Z indicates fluorocarbon seals are standard. Other options are available; contact Pall.

Table 1: Filter Element Options

Code	β <sub>X</sub> (c) ≥1000 based on ISO 16889	CST Rating*		
AZ	3	08/04/01		
AP	5	12/07/02		
AN	7	15/11/04		
AS	12	16/13/04		
AT	22	17/15/08		

<sup>\*</sup> CST: Cyclic Stabilization Test to determine filter rating under stress conditions, based on SAE ARP4205

Table 2: Filter Element Length Options

Code	Length (in)*
13	13
20	20

<sup>\*</sup> Nominal length

## Section 3 (At least one Differential Pressure Indicator or 'B' type blanking plug must be ordered)

#### Differential Pressure Indicator P/N:

Note: Two Differential Pressure Indicators can be fitted on this housing

Table 1: Differential Pressure Indicator Options\*

Code	Indicator	'H' Dim.
778NZ	'P' type Visual indicator with thermal lockout	21mm (0.83in)
860MZ	'D' type Visual indicator with no thermal lockout	21mm (0.83in)
861CZ	'L' type Electrical switch (SPDT) with 6" leads	38mm (1.50in)
861CZ	'M' type Electrical switch (SPDT) with DIN43650 connector and matching cap	78mm (3.07in)
861CZ	'R' type Electrical switch (SPDT) and neon light indicator with DIN43650 connector and cap	89mm (3.50in)
771BZ	'S' type Electrical switch (SPDT) with 3-pin MS connector	57mm (2.24in)

Other options available on application.





Note: If no differential pressure indicator is selected, 'B' type blanking plug (P/N HC9000A104Z) must be ordered separately and fitted to replace the plastic shipping plug.

Note: Z indicates fluorocarbon seals are standard. Other options are available; contact Pall.

Table 2: Differential Pressure Indicator Material

Code	Indicator
Omit	Aluminium Alloy Indicator: use at operating pressures < 200 bar ( < 3000 psi)
SS	Stainless Steel Indicator: use at operating pressures > 200 bar ( > 3000 psi)

'M' & 'R'-Type Table 3

	mulcator codes
Code	Option
YM	'M' option
YR	'R' option

*	Use only if 'R'	or 'M' Indicator is
	selected from	Table 1

Toblo	4. 9	D' Inc	licator	Ο.	otiono
iable	4. 1	חווו ר	ilcator	O	Juons


Table 4.	n indicator options
Code	Option
110AC	110V AC
220AC	220V AC
24DC	24V DC


Use only if 'R' Indicator is selected from Table

<sup>\*</sup> Maximum operating pressure 400 bar

# **UH239 Series Filters**

# HIGH PRESSURE FILTERS Technical Information







#### Pall Industrial Manufacturing

25 Harbor Park Drive
Port Washington, NY 11050
+1 516 484 3600 telephone
+1 800 289 7255 toll free US

Portsmouth-UK +44 (0)23 9230 3303 telephone +44 (0)23 9230 2507 fax

# Visit us on the Web at www.pall.com

Pall Corporation has offices and plants throughout the world. For Pall representatives in your area, please go to www.pall.com/contact

Because of technological developments related to the products, systems, and/or services described herein, the data and procedures are subject to change without notice. Please consult your Pall representative or visit www.pall.com to verify that this information remains valid. Products in this document may be covered by one or more of the following patent numbers: EP 667,800; EP 982,061; EP 1,380,331; EP 1 656 193; US 5,543,047; US 5,690,765; US 5,725,784; US 6,113,784; US 7,083,564; US 7,318,800.

© Copyright 2009, Pall Corporation. Pall, (ALL), and Ultipleat are trademarks of Pall Corporation. ® Indicates a trademark registered in the USA. *Filtration. Separation. Solution.sm* is a service mark of Pall Corporation.