## Naphtha Feed Purification: Major Impacts on Steam Crackers



FCNAPFEEDEN

# CASE STUDY

### Application

One critical application in the ethylene production process is feed stock purification. Contaminated gas or liquid feed stocks can lead to high cost furnace repairs and increased environmental emissions.

### Typical impacts of feed purification are:

- Furnace tubes protection against coke precursors (iron, salts, etc.) and fouling
- Contribution to extended furnace campaign
- Increase of overall production (downtime reduction)
- Maintenance reduction
- Energy saving

The overall positive impacts lead some major licensors and ethylene producers to include the feed filters and coalescer systems in their operations, both on gas and liquid feeds.

Numerous ethylene manufacturing plants observed the negative impacts of feed contamination on their furnaces run times (up to 70% decrease has been noticed), as well as positive impacts of the feed purification.

Process improvements often result from several parameters being optimized, making it difficult to measure the exact impact of each.

Nevertheless, the table on page 2 lists some of the positive feedback that our customers shared with us regarding their operations.

### Introduction

Ethylene production is one of the major areas in which Pall Corporation has been working with leading fuels and petrochemicals companies to make significant advancements to improve fluid contamination management to achieve process optimization, efficiency improvement, and cost savings. Our customers rely on our worldwide and local expertise and technical support, enabling them to choose the best available technologies to optimize their entire operating costs.





### Naphtha Crackers and Related Positive Impacts Linked to the Feed Purification

American Naphtha Cracker #1	<ul> <li>33% increase of furnace run time after installation of prefilters &amp; liquid/liquid coalescers (\$2M savings/year)</li> <li>Payback &lt;10 months</li> <li>Reduction of maintenance, CO formation, CO2 emissions, fuel consumption</li> <li>Better control of Naphtha/steam ratio</li> </ul>
American Naphtha Cracker #2	<ul> <li>Without filters &amp; coalescers:</li> <li>With prefilters only:</li> <li>With prefilters &amp; coalescers:</li> <li>With prefilters &amp; coalescers:</li> <li><b>19 days</b> furnace run time</li> <li><b>55 days</b> furnace run time</li> </ul>
American Naphtha Cracker #3	<ul> <li>More than 40% furnace run time reduction compared to the design, without feed purification</li> <li>Losses of production and high maintenance costs</li> <li>Recovery of +/- 95% of the overall furnace run length design after the installation of Naphtha feed prefilters and coalescers</li> </ul>
European Naphtha Cracker #1 & 2	<ul> <li>Installation of Naphtha feed prefilters and coalescers on the first cracker</li> <li>Following positive results, installation of the same equipment on the second cracker</li> <li>Positive impacts confirmed – bypass of the installation can lead to a 50% reduction in furnace run length</li> </ul>
European Naphtha Cracker #3	Naphtha feed prefilters and coalescers installation payback of 6 months
Chinese Naphtha Cracker	<ul> <li>Installation of Naphtha feed prefilters and coalescers in front of 4 furnaces</li> <li>Increase of furnace run length from 11 to 17 days</li> </ul>

#### **Customer Benefits**

The major benefits of using high-efficiency liquid/liquid coalescers and absolute-rated filters include:

- Reduction of fouling in the furnace convection zone
- Extension of the run time length of the furnaces between de-coking
- Increase in the useful life of the furnace tubes
- Lowering of emissions

This technology also enables ethylene plants to use more contaminated, alternate feed stocks such as Naphtha brought in by marine transport or Light Cat-cracked Naphtha (LCN / FCC gasoline) coming from refineries. The payback period for the capital investment in the high-efficiency liquid/liquid coalescers associated with the prefilter systems was estimated to be less than one year.

### Conclusion

High-efficiency liquid/liquid coalescers and absolute-rated prefilters (99.98% efficiency) used to treat liquid or gas hydrocarbon feeds in ethylene plants were found to increase the steam cracker productivity and to lower emissions by decreasing the de-coking frequency.

In crackers fed with barged Naphtha, the highefficiency liquid/liquid coalescers removed fouling and coke generating contaminants, including sodium. Prefilters and coalescers successfully protected the new generation of furnaces at several ethylene plants.



#### **Corporate Headquarters**

Port Washington, NY, USA +1-800-717-7255 toll free (USA) +1-516-484-5400 phone

## European Headquarters

Fribourg, Switzerland +41 (0)26 350 53 00 phone

## Asia-Pacific Headquarters

+65 6389 6500 phone

#### Visit us on the Web at www.pall.com/industry Contact us at www.pall.com/contact

Pall Corporation has offices and plants throughout the world. To locate the Pall office or distributor nearest you, visit www.pall.com/contact.

The information provided in this literature was reviewed for accuracy at the time of publication. Product data may be subject to change without notice. For current information consult your local Pall distributor or contact Pall directly.

*IF APPLICABLE* Please contact Pall Corporation to verify that the product conforms to your national legislation and/or regional regulatory requirements for water and food contact use.

© Copyright 2023, Pall Corporation. Pall and (PALL) are trademarks of Pall Corporation. ® Indicates a trademark registered in the USA.

FCNAPFEEDE June 2023