

Polymers: Application Focus

Ultipleat® Polymer Candle doubles the filtration capacity at PET producer

A major PET resin and fiber producer in Europe produces very high-quality polyester staple fibers, filament yarns and specialty polymers including PET resins for various applications and industries. They operate multiple batch and continuous polymerization and fiber production lines. The monomer dimethyl terephthalate (DMT) is produced on site.

The continuous plants have a duplex type central filtration system, which is used for melt filtration, both from Pall or from other suppliers. It is critical to filter the contamination and the gel from the PET melt to ensure the quality of the final product and increase the spin pack life at the spinnerets.



The PET manufacturer operates central filtration systems, one of the lines uses twenty seven (27) candles per housing and the other one uses thirty seven (37) candles per housing. Each candle provides 0.96 m² (10.35 ft²) in filter area.

Historically, the customer had worked with two major European element suppliers of fan pleat element design and found marginal improvements in onstream life while switching from one supplier to another. These two plants are producing various specialty PET resins in various intrinsic viscosities and with different additives with frequent changes.



Challenge

The customer wanted to see the performance of the Pall technology and test it in the most challenging production unit. If tests go well, they indicated to apply it to other manufacturing plants, where they wanted to increase the capacity and the onstream life.

This manufacturing line typically needed 3 sets of replacement elements a year. From their experience, every set of the fan pleat elements was able to filter about 10,000 tonnes of polymer per year.


An onstream life comparison did not make sense because of the frequent product changes, therefore a long-term (12 month) comparison was planned. The goal was to:

- Increase the amount of polymer filtered per set
- Improve the on-stream life of the filters
- Reduce the number of sets to be purchased every year
- Reduce operating costs

Pall solution

These systems had fan pleat type filter candles. Two sets of Ultipleat polymer filter candles, using the Laid Over Pleat (LOP) design, were purchased to be used in one of the continuous PET resin plants.

A bundle of twenty eight (28) filter candles with similar dimensions and micron ratings were designed to retrofit the customer's existing housing in the first line. The filter housing was kept unchanged, only the internals were replaced to fit the new Pall elements. Each Ultipleat polymer candle provided 1.2 m² (12.92 ft²) in filter area, an



Pall Laid Over Pleat (LOP)

Ultipleat Polymer Candle doubles the filtration capacity at PET producer

increase of approximately 25% over the existing candles. The goal for the new Pall filter candles was set to filter at least 15,000 tonnes of polymer per set.

The comparison test between the Ultipleat polymer candle and the competitor's elements started at the beginning of 2017.

By December 2019, 24,500 tonnes of polymer has been filtered with one set of Ultipleat filters, exceeding the original target by 160%, and the competitor performance by near to 250%. They are still in use after more than 25 cleaning cycles without any mechanical and material damages.

In 2019, Pall delivered the next generation Ultipleat Plus candles, hich has even more filter area, providing 1.45 m² (15.56 ft²) in filter media area, an increase of 50% over the fan pleat candles. These candles have been in use in the other production line with thirty seven (37) candles per housing. 8,600 tonnes of polymer has been filtered through one set within 9 months, and has been cleaned seven times without any issues.

Benefits

- The customer observed no reduction in quality of the PET resins
- The Ultipleat candles were cleaned with the existing cleaning procedure successfully
- They reduced the number of sets by 50%, which they have to buy every year
- On-stream life is increased due to more filter surface resulting an estimated annual cost savings per line is in excess of \$50,000



Ultipleat Plus after 7 cleaning cycles

Conclusion

The customer is satisfied with Pall's Ultipleat polymer candle technology and is planning to phase out all current fan pleat candles to be replaced with Ultipleat polymer filter candle technology.



Pall Industrial

25 Harbor Park Drive
Port Washington, NY 11050
+1 516 484 3600 telephone
+1 800 289 7255 toll free US

Portsmouth - UK +44 (0)23 9233 8000 telephone +44 (0)23 9233 8811 fax www.pall.com/contact





Pall Corporation has offices and plants throughout the world. For Pall representatives in your area, please go to www.pall.com/contact

Because of technological developments related to the products, systems, and/or services described herein, the data and procedures are subject to change without notice. Please consult your Pall representative or visit www.pall.com to verify that this information remains valid.

© Copyright 2019, Pall Corporation. Pall PALD, and Ultipleat are trademarks of Pall Corporation.

® Indicates a trademark registered in the USA. Better Lives. Better Planet. and Filtration. Separation. Solution.sw. are service marks of Pall Corporation.