


Pall Aerolith® S Filter Elements

Description

Pall **Aerolith S** filter material is a further development of the well-known Pall® product **Aerolith** with improved properties. Composed of selected high quality ceramic raw materials, the aluminosiliceous filter material **Aerolith S** is produced in a controlled production process as a cylinder, candle or tile. The special merits of **Aerolith S** filter elements are the higher mechanical stability as well as an improved pH resistance in the alkaline range. Due to the porous labyrinth structure with high particle storage capacity, **Aerolith S** filter elements are well suited for depth filtration applications up to temperatures of 700°C.



Applications

Cylinders

- Particle filtration of Liquids Acids, water and alcohol
- Particle filtration of Gases Process gases, mixed gas, air, sewer gas, natural gas, and liquid gas
- Coalescer Compressed air, nitrogen and carbon dioxide
- Storing Media Water, colour and ink
- Vacuum Lance Retention of fire extinguishing powder

Plates

- Nutsches Mud thickening

General Information

- Porous **Aerolith S** ceramic is approved for the utilization in drinking water according to German regulations DVGW W270 and the KTW recommendation.
- **Aerolith S** filter elements can be machined using hard metal tools.
- Ceramic elements are to be handled with care.
- Elements can be easily glued using commercial glues which Pall can supply. Consideration must be paid to operating temperature and chemical resistance.
- Pall can supply a variety of element fixing systems.

Chemical Resistance³

Aerolith S filter elements are resistant against most acids, saline solutions and organic solvents, liquid or gaseous. It does not resist hydrofluoric acid. **Aerolith S** filter elements are resistant up to pH 10 in the alkaline range.

³ As end use conditions can vary, it is the users responsibility to verify compatibility with their specific use conditions


Technical Information

Flow vs Differential Pressure

| Aerolith S (AES) | Cylinders / Plates | | | |
|---|-------------------------------------|-------------------------------------|--------------------------------------|--------------------------------------|
| | AES 05 | AES 10 | AES 20 | AES 30 |
| Filtration of Gases ¹ | < 1 µm | 1.5 µm | 2.5 µm | 5 µm |
| Porosity | 40 % | 40 % | 40 % | 40 % |
| Material Density | 1.5 g/cm ³ | 1.5 g/cm ³ | 1.5 g/cm ³ | 1.5 g/cm ³ |
| Specific Permeability | 25 10 ⁻¹³ m ² | 50 10 ⁻¹³ m ² | 100 10 ⁻¹³ m ² | 250 10 ⁻¹³ m ² |
| O-Ring Strength Compression | > 10 MPa | > 10 MPa | > 9 MPa | > 8 MPa |
| Maximum Temperature Resistance ² | 700 °C | 700 °C | 700 °C | 700 °C |
| Expansion Co-efficient (25 - 200 °C) | 3.0 10 ⁻⁶ /K | 3.0 10 ⁻⁶ /K | 3.0 10 ⁻⁶ /K | 3.0 10 ⁻⁶ /K |
| Expansion Co-efficient (25 - 700 °C) | 4.7 10 ⁻⁶ /K | 4.7 10 ⁻⁶ /K | 4.7 10 ⁻⁶ /K | 4.7 10 ⁻⁶ /K |
| Dimensions (Do / Di) | 70 / 40 mm | 70 / 40 mm | 70 / 40 mm | 70 / 40 mm |

¹ PSG Retention efficiency test 99.98%

² Depending on operating conditions



Ordering Information

| Part Number | Aerolith (AES) | Type | Do / Di (mm) | Length (mm) | Area (m ²) | Weight (kg) |
|-------------|----------------|------|--------------|-------------|------------------------|-------------|
| 89580483 | Cylinder | 10 | 40 / 20 | 80 | 0.010 | 0.1 |
| 89580051 | | 20 | 40 / 20 | 80 | 0.010 | 0.1 |
| 89580480 | | 10 | 60 / 40 | 500 | 0.095 | 1.2 |
| 89580054 | | 30 | 60 / 40 | 500 | 0.095 | 1.2 |
| 89580476 | | 5 | 60 / 40 | 1000 | 0.188 | 2.4 |
| 89580477 | | 10 | 60 / 40 | 1000 | 0.188 | 2.4 |
| 89580478 | | 20 | 60 / 40 | 1000 | 0.188 | 2.4 |
| 89580053 | | 30 | 60 / 40 | 1000 | 0.188 | 2.4 |
| 89580452 | | 5 | 70 / 40 | 1000 | 0.220 | 3.9 |
| 89452208 | | 10 | 70 / 40 | 1000 | 0.220 | 3.9 |
| 89580050 | | 20 | 70 / 40 | 1000 | 0.220 | 3.9 |
| 89580055 | | 30 | 70 / 40 | 1000 | 0.220 | 3.9 |

| Part Number | Aerolith (AES) | Type | Length (mm) | Width (mm) | Height (mm) | Area (m ²) | Weight (kg) |
|-------------|----------------|------|-------------|------------|-------------|------------------------|-------------|
| 89582167 | Plate | 20 | 250 | 250 | 52 | 0.063 | 4.8 |

Please contact Pall for enquiries relating to dimensions not specified above.



Pall Corporation

Pall Industrial

New York - USA
 +1 516 484 3600 telephone
 +1 888 333 7255 toll free
 +1 516 484 6247 fax

Portsmouth - UK
 +44 (0)23 9230 3303 telephone
 +44 (0)23 9230 2507 fax

Filtration. Separation. Solution.SM

Visit us on the Web at www.pall.com

Pall Corporation has offices and plants throughout the world. For Pall representatives in your area, please go to www.pall.com/corporate_contact.asp

Because of technological developments related to the products, systems, and/or services described herein, the data and procedures are subject to change without notice. Please consult your Pall representative or visit www.pall.com to verify that this information remains valid.

© Copyright 2008, Pall Corporation. Pall, and Aerolith are trademarks of Pall Corporation. ® Indicates a trademark registered in the USA. Filtration. Separation. Solution.SM is a service mark of Pall Corporation.