

UMO Series Filter Housings

Industrial ASME Code High Pressure, Multi-Cartridge Filter Housings

- Accepts Six 10" (25.4 cm), 20" (50.8 cm), 30" (76.2 cm) or 40" (102 cm) DOE Style Filter Cartridges
- Standard Materials of Construction are Carbon Steel or 316 Stainless Steel. 316L Stainless Steel is Available as an Option. Contact Pall for Details.
- 300 psig (20.7 bar) Maximum Operating Pressure Permits Use in a Wide Range of Applications
- Housings Can Be Modified to Accept M3 (Code 3) Style
 Filter Cartridges
- Multiple Eyebolt Design Allows Quick, Easy Cartridge Change-Out
- Accu-Seal[™] Sealing Device and Uni-Seal[™] Sealing Device Options are Available

Housing Specifications

Maximum Operating Pressure:

Carbon Steel: 300 psig (20.7 bar) @ 500°F (260°C) Stainless Steel: 300 psig (20.7 bar) @ 200°F (93°C)

> ASME UM Stamp¹ ASME U Stamp

Connections:

Optional:

Construction: Standard:

 Inlet/Outlet:
 2" NPT

 Drain:
 ½" NPT

 Vent:
 ¼" NPT

Connection Option:

300 lb. ANSI, 2" slip-on flanges

Shell O-Rings:

Nitrile (standard), Silicone Elastomer, Neoprene, Ethylene Propylene, Fluorocarbon Elastomer

Closure Bolts:

Zinc Plated Carbon Steel (standard)²

Reverse Flow Option:

Dimensional Data

Housings can be modified for reverse flow applications. Consult factory for further information.

Internal Components:

The universal seat plate is made of 316L stainless steel for both the carbon steel and 316 stainless steel vessels. Top seat plate assemblies and tube guides are standard with internal parts option. Accu-Seal sealing and Uni-Seal sealing mechanisms are optional.

- ¹ Certain UMO Series housings require ASME U stamp.
- ² Stainless materials are optional and require design considerations. For inquiries contact the factory.
- ³ Flow rates listed are for depth cartridges. Consult factory for more specific information.

Model	Flow Rate ³ gpm (lpm)	No. of 10" Equivalents	"A" Maximum Height in (cm)	Dry Weight Ib (kg)
Carbon Steel				
6UMO1	to 30 (114)	6	29 (73.7)	85 (39)
12UMO2	to 60 (227)	12	39 (99.1)	95 (43)
18UMO3	to 90 (341)	18	50 (127.0)	105 (48)
24UMO4	to 120 (454)	24	60 (152.4)	115 (52)
316 Stainless S	iteel			
6UMO1S	to 30 (114)	6	29 (73.7)	85 (39)
12UMO2S	to 60 (227)	12	39 (99.1)	95 (43)
18UMO3S	to 90 (341)	18	50 (127.0)	105 (48)
24UMO4S	to 120 (454)	24	60 (152.4)	115 (52)

Dimensional Drawing - Side View

Vent 目 Swing Bolts Top Seat Plate 9 Α 0-Ring 9" (22.9 cm) Мах **Tube Guide** Filter Cartridge 15" (38.1 cm) 10 ¾" (27.3 cm) Inlet Body 6" (15.2 cm) Drain Outlet 8" (20.3 cm) Universal Seat Plate Sump Drain

Housing Differential Pressure vs. Liquid Flow Rate



For liquids other than water, multiply differential pressure by specific gravity.

Part Numbers/Ordering Information

■ UMO ● ▶ - 2 ▼ - C300 ▶ - ◎ (e.g., 6UMO1S-2F-C300U-IP)

Code	No. of 10" Equivalents	Code	No. of Decks
6	6	1	1
12	12	2	2
18	18	3	3
24	24	4	4

⁴ Standard vessels include internal parts of top seat plates and tube guides. Basic vessels without internal parts may be ordered as non-stock items.

Code	Materials of Construction	Code	ASME Stamp Designation
Blank	Carbon Steel	U	U Stamp
S	316 Stainless Steel	UM	UM Stamp
Code	Connection	Code ©	Internal Parts ⁴
Code	Connection Styles	Code © Blank	Internal Parts⁴ No Internal Parts
Code Blank	Connection Styles NPT	Code © Blank IP	Internal Parts ⁴ No Internal Parts Internal Parts



New York - USA

+1 516 484 3600 telephone +1 888 873 7255 toll free +1 516 484 0364 fax

Portsmouth - UK

+44 (0)23 9230 2357 telephone +44 (0)23 9230 2509 fax

Visit us on the Web at www.pall.com

Pall Corporation has offices and plants throughout the world. For Pall representatives in your area, please go to www.pall.com/corporate_contact.asp.

Because of technological developments related to the products, systems, and/or services described herein, the data and procedures are subject to change without notice. Please consult your Pall representative or visit www.pall.com to verify that this information remains valid.

© Copyright 2008, Pall Corporation. Pall, (Acu-Seal, and Uni-Seal are trademarks of Pall Corporation. © Indicates a Pall trademark registered in the USA. *Filtration. Separation. Solution.sm* is a service mark of Pall Corporation.