

Description

The MCC1401 filter cartridge is available in two basic types of media; Epocel® – which is a resin impregnated cellulose, and Ultipor® – a resin bonded glass fiber. These absolute rated media, specifically engineered, are available in varying grades with defined removal efficiencies and can provide up to 54 square feet of effective filtering surface area assuring long service life. See Table 1 for removal ratings of each medium type.

Operating Characteristics


MCC1401 cartridges are of pleated design, supported internally by a steel core and protected externally by steel endcaps, providing positive sealing via an internal O-ring. The maximum recommended changeout differential pressure is 60 psid/4.13 bar at 275°F/135°C.

Filter Media Characteristics

Ultipor Filter Cartridges: These cartridges are ruggedly built using a resin bonded glass fiber medium. The inert resin bonding ensures that the filters are free from media migration and establishes a permanent, fixed pore construction that prevents unloading of trapped contaminants. Because of their high effective filter area and optimized construction, Ultipor elements provide high dirt holding capacity, low clean pressure drop, long service life and low cost per gallon of fluid processed.

Epocel Filter Cartridges: This filter medium is comprised of a resin impregnated cellulose medium. Utilizing the resin impregnation technique locks the cellulose fibers in place preventing flexing or shifting, which can change the size of the flow passages and reduce removal efficiency. Epocel medium is compatible with many fluids including fresh and produced water, acids, solvents, brines, hydrocarbons, alcohols, and many others. Epocel cartridges are available in grades ranging from 10 micron up to 50 micron absolute.

MCC1401 High Pressure Filter Cartridge Providing Reliability and Economical Filtration for Superior Fluid Quality



MCC1401 Filter Cartridge

Applications

Fluid Processing: Solvents, acids, chemicals, hydrocarbons, water and other fluids used in refinery, chemical and petrochemical processing always carry some harmful particles that must be removed. MCC1401 cartridges provide the fine filtration necessary to adequately clean up these fluids. Their durability, large amount of filtration area and high dirt capacity have proven to be most beneficial for this type of filtering.

High Pressure Gas Streams: Finer grades of the MCC1401 cartridge, offered for use in gas systems, will remove over 99.98% of all solid aerosols suspended in a gas stream. The effluent gas, produced after Pall filtration, will not plug sensitive instruments or foul critical machine components such as a compressor or turbine blades.

High Pressure Water Injection and Disposal:

The MCC1401 high pressure filter cartridge provides reproducible high quality injection fluids for your waterflood and enhanced oil recovery operation. Injecting high quality fluids reduces formation damage, maintains stable injection profiles, and increases sweep efficiency that lowers operating expenses because of less frequent workovers.

Table 1. MCC1401 Elements - Performance Characteristics

Cartridge Part Number	Liquid Removal Rating				Gas Removal	Effective	Media	Element Aqueous Pressure Drop	
	Percent Removal 99.98% ¹ 99% 90%		90%	⁻ Rating Percent ₋ Removal⁵	Area ³	Description	Pressure	ьгор	
	Beta ^{2, 5}	5000	100	10	Tiemovai	Sq. ft.		psid/gpm	mbar/lpm
MCC1401U2-20ZH13	(2) (4)	2.0	0.8	0.3	>99.99 at 0.3 micron	54	Ultipor Resin Bonded Glass	0.021	0.382
MCC1401U6-40ZH13	(2) (4)	2.5	<1.0	<1.0	>99.98 at 0.3 micron	53	Ultipor Resin Bonded Glass	0.0015	0.027
MCC1401E100H13	(2) (4)	10.0	5.0	<2.0	95.7 at 0.3 micron	37	Epocel Resin Impregnated Cellulose	0.005	0.091
MCC1401E280H13	(2) (4)	23.0	16.0	8.0		45	Epocel Resin Impregnated Cellulose	0.002	0.036
MCC1401E500H13	(2) (4)	50.0	44.5	27.0		45	Epocel Resin Impregnated Cellulose	0.0017	0.031

Absolute Filtration Rating: The absolute rating can be operationally defined as βλ = 5000 or 99.98% removal efficiency at any given size.
 Note: This is the limit of the sensitivity of the rating method.

- (5) Specially designed for high temperature applications.
- (6) Per sodium chloride aerosol test. Figures are in % of particles removed at specified size or larger.
- (7) Pressure drop in PSID per GPM for the cartridge shown. Multiply this value by the total system flow to determine the aqueous pressure drop. Next for fluids other than water, multiply this value by the fluid's viscosity at the operating temperature in centipoise. This is the pressure drop value across the filter. It must be added to the pressure drop due to the housing. See Figures 1 and 2.

Housing Information

A full line of standard and special MCC1401 housings, which are designed and built to the ASME code, are available. Refer to Table 2 and Figure 1 for more information.

Table 2. Standard MCC1401 Housings – Carbon Steel, Rated at 285 psig/19.6 bar and 100°F/37°C


Part Number	Number of Filters	Nominal Vessel Diameter in/mm	Inlet/Outlet Flange Size in/mm	Housing Height in/mm	Housing Weight (empty) lb/kg	Housing Weight (full) lb/kg
1MCC0603F1285	1	6.625 / 168.3	3 / 76.2	54.25 / 1378	200 / 91	250 / 113
4MCC1004F1285	4	10.75 / 273.1	4 / 101.6	59 / 1498.6	440 / 199	585 / 265
5MCC1206F1285	5	12.75 / 323.9	6 / 152.4	64 / 1625.6	680 / 308	925 / 419
9MCC1608F1285	9	16 / 406	8 / 203.2	84 / 2133.6	1070 / 485	1570 / 712
15MCC2010F1285	15	20 / 508	10 / 254	93 / 2362.2	2000 / 907	2750 / 1247
19MCC2412F1285	19	24 / 609.6	12 / 304.8	110 / 2794	2300 / 1043	3500 / 1587

⁽²⁾ Beta Value (β): β is the ratio of the number of particles equal to a given size or larger in the influent compared to those of the same size or larger in the effluent. β is related to the removal efficiency by: Removal Efficiency % = β-1 x 100

⁽³⁾ Area listed is for basic 3%4" O.D. by 40" nominal length cartridge.


⁽⁴⁾ Ratings determined using 0.5 μm to 40 μm siliceous contaminant for MCC1401U2-20. For other MCC1401 cartridges, ratings determine using AC-Fine Test Dust in a water dispersion for a test system.

Figure 1. MCC1401 Housings - Aqueous Pressure Drop



Flow (gallons per minute)

(1) To calculate the actual housing pressure drop, multiply this aqueous pressure drop by the fluid's specific gravity. This value must be added to the filter pressure drop to calculate the overall pressure drop of the filter system.



Flow (liters per minute)

(1) To calculate the actual housing pressure drop, multiply this aqueous pressure drop by the fluid's specific gravity. This value must be added to the filter pressure drop to calculate the overall pressure drop of the filter system.



25 Harbor Park Drive
Port Washington, NY 11050
+1 516 484 3600 telephone
+1 888 873 7255 toll free US

Portsmouth - UK +44 (0)23 9230 2357 telephone +44 (0)23 9230 2509 fax processuk@pall.com

Visit us on the Web at www.pall.com

Pall Corporation has offices and plants throughout the world. For Pall representatives in your area, please go to www.pall.com/contact

Because of technological developments related to the products, systems, and/or services described herein, the data and procedures are subject to change without notice. Please consult your Pall representative or visit www.pall.com to verify that this information remains valid.

© Copyright 1991, 2009, Pall Corporation. Pall, (PALL) are trademarks of Pall Corporation.

® Indicates a Pall trademark registered in the USA. *Filtration. Separation. Solution.sm* is a service mark of Pall Corporation.