

Refineries: Application Focus

H₂SO₄ Alkylation

Process Description

Olefins (C3-C4) from the FCC unit are combined with isobutane (i-C4). Concentrated Sulfuric Acid (H₂SO₄) is then mixed in and fed to the reactor that is operated with refrigeration to minimize formation of by-products. The alkylation reaction takes place combining the olefins with the isobutane to form the alkylate product which consists of high octane value products that are later blended into the gasoline pool. The hydrocarbons leaving the reactor mostly consist of alkylate, unreacted isobutane, n-butane, and propane.

The acid and alkylate product are separated by a settler and the acid is recovered for re-use in the reactor. The reactor hydrocarbons are separated by the main fractionator where the isobutane is recycled to the reactor, alkylate is drawn of the bottom and an n-butane product stream is separated from a side stream.

The light ends of the process fluids are used in the refrigeration loop and a side stream is passed through a propane stripper to recover propane.

Effective separation is a critical component of an efficient, reliable and safe H_2SO_4 alkylation process.

Ensure your Alkylation unit operates reliably, with minimum corrosion, low acid consumption, and on spec products



Refinery Needs

- Equipment reliability / minimized corrosion to meet 4-6 year refinery turn around schedule
- Meet product specs for high octane value alkylate and caustic free propane
- Low acid makeup costs by minimizing acid dilution from wet feedstocks
- Maintain high levels of safety by avoiding any equipment failures that could lead to fugitive acid emissions

Challenge	Solution	
Meet product specifications	 Improve refinery productivity and product specifications by removal of water from the olefin and isobutane hydrocarbon reactor feed streams and by removing any carryover caustic in the propane. High efficiency AquaSep XS[®] and PhaseSep[®] liquid/liquid coalescers reliably meet 'clear and bright' product specification and sodium levels downstream. 	
Protect fractionator towers from corrosion & plugging	 Improve protection of main fractionator/isobutane stripper and propane stripper. High efficiency PhaseSep liquid/liquid coalescers reliably remove caustic from the feed to the main fractionator / isobutane stripper and to the propane stripper tower to prevent corrosion and fouling of the internal trays. 	
Control acid makeup costs	 Ensure the high sulfuric acid strength is maintained. High efficiency AquaSep XS or PhaseSep liquid/liquid coalescers remove free water directly leading to acid dilution and need for replacement 	

Production Challenge/Pall Solution

Process Flow Diagram



Note: A representative sulfuric acid alkylation process is shown. Other specific alkylation processes exist.

Key Applications / Filter Recommendations (other applications not shown)

	Application	Pall Product	Advantages	Customer Benefits
1 3 5	Pre-filtration prior to liquid/liquid coalescer	Ultipleat [®] High Flow filter or Profile [®] Coreless PPS	Efficient removal of solids	Lower operating costs by improving the life of the liquid/ liquid coalescer
2	Feed/isobutane recycle stream water removal	AquaSep XS (or PhaseSep) liquid/liquid coalescer	Remove water (or caustic) from reactor feed hydrocarbons	Prevent dilution of acid catalyst and potential for corrosion and poor product yields
4	Caustic removal from feed to propane stripper	PhaseSep liquid/liquid coalescer	Remove carryover caustic	Reduce corrosion in propane stripper and meet propane quality spec
6	Caustic removal from feed to main fractionator/isobutane stripper	PhaseSep liquid/liquid coalescer	Remove carryover caustic	Reduce corrosion in main fractionator and meet butane and alkylate purity specs

For fast track upgrades, NO CAPEX:

Pall-Fit filter and coalescer retrofits enable a move to Pall quality without change to your existing filter housing Pall filter and coalescer housing rentals enable a technology upgrade for rapid problem resolution

PALL Pall Corporation

Fuels and Chemicals

25 Harbor Park Drive Port Washington, New York 11050 +1 516 484 3600 telephone +1 888 873 7255 toll free US

www.pall.com/contact





Visit us on the Web at www.pall.com

Pall Corporation has offices and plants throughout the world. For Pall representatives in your area, please go to www.pall.com/contact.

Because of technological developments related to the products, systems, and/or services described herein, the data and procedures are subject to change without notice. Please consult your Pall representative or visit www.pall.com to verify that this information remains valid. Products in this document may be covered by one or more patent numbers. For a complete list of Pall's patents please visit http://www.pall.com/main/about-pall/patents.page

© Copyright 2018 Pall Corporation. Pall, (AquaSep, PhaseSep, Profile, and Ultipleat are trademarks of Pall Corporation. ® Indicates a Pall trademark registered in the USA. *Filtration. Separation. Solution.sw* and **BETTER LIVES. BETTER PLANET.** are service marks of Pall Corporation.

FCREFH2SO4ALKYENa