

Ultipor® HT Series Filter Elements

Description

Ultipor® HT filters have a pleated, high area construction for long service life. The unique medium structure consists of a high temperature binder resin which coats the fine glass fibers. The filter's materials of construction are qualified for uses up to $425^{\circ}F$ ($218^{\circ}C$) with compatible fluids. The double open ended filters are installed over a tie rod/seal nut assembly. The flow pattern is outside to inside.

Benefits

- · Optimized pleat pack filtration helps to develop filter cake
- · Batch to batch consistency
- Core collapse pressure rated to 75 psid (5.17 bard) @ 425°F (218°C)
- Available with retention ratings of 1, 10, 20, and 70 micron (µm)¹
- Able to process tough oil fractions, containing fine suspended solids
- · Large surface area provides long service life

Performance Specifications

Filter Grades (rated at 99% efficiency):² 1, 10, 20, 70 µm

Maximum Temperature:

425°F (218°C)

Maximum Forward Differential Pressure:3

40 psid (2.75 bard) @ 425°F (218°C)

Recommended Changeout Differential Pressure:

30 psid (2.0 bard) @ 425°F (218°C)

Product Specifications

Materials of Construction:4

Filter Media: Resin bonded glass fiber on aramid

substrate

Drainage Mesh: Steel Support: Glass

Gaskets: Graphite Sheet,

Fluorocarbon Elastomer

Adhesives: Epoxy Resin

Core/End Caps: Carbon Steel (zinc plated)



Dimensions (nominal):

Outside Flange

Diameter: 6.12 inch (15.54 cm)

Outside Filter

Diameter: 6 inch (15.24 cm)

Inside Filter

Diameter: 3.45 inch (8.76 cm) Length: 44 inch (111.76 cm)

¹ For information to order these grades, consult your local Pall representative.

² The test procedure used is an adaptation of ISO 16889, modified to

determine the micron size above which particles are quantitatively removed.

Normal flow direction is outside-to-inside. Reverse flow operation is not recommended.

⁴ Ultipor HT elements are manufactured by Pall to exacting procedures and strict quality controls.

Housing Information

ASME rated filter vessels are available in a variety of materials including carbon steel, stainless steel, and other alloys to meet service requirements. Vessels may also be custom built to comply with other regional and local codes and practices. Please contact your local representative to discuss fabrication specifications, instrumentation, piping/manifolding needs, and skid mounting.

Applications

Ultipor HT filters are designed for a variety of applications. These high temperature filters are frequently used to process tough oil fractions, containing fine suspended solids typically found in processes related to desulphurization and fuels upgrading. These fluids, left untreated, can reduce reactor runtime and foul critical process equipment. Other applications include:

- · Heated tank farm fluids
- Reactor bed feed filtration (e.g. Hydrotreaters)
- · Heat exchanger protection
- · Gas to liquid wax products
- · Lubricant processing
- · Hydrogenation product polishing
- · Hot motor fuel product blending

Liquid Retention Ratings (μ m) (ISO 16889 modified)

Cartridge Designation	99%Efficiency (Beta 100)
GK010	1
GK100	10
GK200	20
GK700	70


Part Numbers/Ordering Information

HT0644 ■ ◆ (e.g., HT0644GK200G)

Code	Filter Grades (micron)	(
GK010	1	
GK100	10	
GK200	20	•
GK700	70	

Code ◆	Gasket Materials
G	Graphite Sheet
Н	Fluorocarbon Elastomer

Typical Flow vs. Differential Pressure for Application Sizing





New York - USA

+1 516 484 3600 telephone

+1 888 873 7255 toll free

+1 516 484 0364 fax

Portsmouth - UK

+44 (0)23 9230 2357 telephone

+44 (0)23 9230 2509 fax

Visit us on the Web at www.pall.com

 $Pall\ Corporation\ has\ offices\ and\ plants\ throughout\ the\ world.\ For\ Pall\ representatives\ in\ your\ area,\ please\ go\ to\ www.pall.com/corporate_contact.asp.$

Because of technological developments related to the products, systems, and/or services described herein, the data and procedures are subject to change without notice. Please consult your Pall representative or visit www.pall.com to verify that this information remains valid.

© Copyright 2009, Pall Corporation. Pall, (PALL) and Ultipor are trademarks of Pall Corporation.

® Indicates a trademark registered in the USA. Filtration. Separation. Solution.sw is a service mark of Pall Corporation.