

# Athalon™ Filters

## Overview of Validation Process

### Athalon Filters Product Overview

Athalon filter elements incorporate Pall Corporation's advanced filter medium pack construction that benefits from Stress-Resistant filter medium Technology (SRT) along with other material upgrades. These upgrades include specially blended layers of fiberglass, optimized construction for low differential pressure and stress resistance, tapered pore construction, uniform pore size control layer and epoxy resin bonded fiber structure. Athalon filters are rated  $\text{Beta}_{x(c)} > 2000$ .

The Athalon filter element validation process included a Production Qualification Process and Internal Laboratory Filter Testing per ISO Filter Test Standards.

### Production Qualification of Athalon Filter Elements

A Production Qualification process was carried out on the Athalon filter elements in order to confirm manufacturing process capabilities, clarify SPC (Statistical Process Control) requirements for defined critical to quality measurements, clarify the requirements for releasing Athalon work cells for production and document requirements for production at Pall manufacturing sites. Upon successful completion of the Production Qualification process, representative Athalon filter element samples were manufactured for internal laboratory filter testing.

### Pall Internal Laboratory Testing

Internal laboratory filter testing per ISO Filter Test Standards on the Athalon filter elements was conducted in order to generate product performance claims and specifications. All testing is complete and the results show that the Athalon filter elements have met the performance goals.

This internal laboratory testing included:

1. Material Compatibility per ISO 2943 - Verified by heat soak for 72 hours at 15°C (27°F) higher than the above rated maximum temperatures in a series of fluids and qualified by similarity to Ultipor® III and Ultipleat® SRT filter element materials.
2. Fabrication integrity per ISO 2942, "Hydraulic fluid power – Filter elements – Verification of fabrication integrity and determination of the first bubble point".
3. Clean Element differential pressure per ISO 3968 - "Hydraulic fluid power – Filters – Evaluation of pressure drop vs. flow characteristics".
4. Filtration ratios and dirt capacity per ISO 16889, "Hydraulic fluid power filters – Multi-pass method for evaluating filtration performance of a filter element".
5. Collapse ratings per ISO 2941, "Hydraulic Fluid Power – Filter Elements – Verification of collapse/burst resistance".
6. Stress-Resistance Test and Cyclic Stabilization ratings per SAE ARP 4205, "Aerospace fluid power – Hydraulic filter elements – Method for evaluating dynamic efficiency with cyclic flow".



Athalon Filter Elements

*This document is the confidential work product of Pall Corporation and no portion of this document may be copied, published, performed, or redistributed without the express written authority of a Pall corporate officer. This document is furnished for use by the assigned recipient only. This material is confidential and is not to be divulged to others without specific written permission from Pall Corporation.*



#### Pall Machinery and Equipment

25 Harbor Park Drive  
Port Washington, NY 11050  
+1 516 484 3600 telephone  
+1 800 289 7255 toll free US

Portsmouth - UK  
+44 (0)23 9233 8000 telephone  
+44 (0)23 9233 8811 fax  
industrial@pall.com

*Filtration. Separation. Solution.<sup>SM</sup>*



#### Visit us on the Web at [www.pall.com](http://www.pall.com)

Pall Corporation has offices and plants throughout the world. For Pall representatives in your area, please go to [www.pall.com/contact](http://www.pall.com/contact)

Because of technological developments related to the products, systems, and/or services described herein, the data and procedures are subject to change without notice. Please consult your Pall representative or visit [www.pall.com](http://www.pall.com) to verify that this information remains valid.

© Copyright 2015, Pall Corporation.

Pall, (PALL) and Athalon are registered trademarks of Pall Corporation.  
® indicates a trademark registered in the USA. Better Lives. Better Planet and **Filtration. Separation. Solution.<sup>SM</sup>** are service marks of Pall Corporation.