

FMC-22 DRUM FILTERS



Introduction

For filling lines, FSI offers the answer for the final filtration stage with the FMC-22, a light-weight, easily maneuvered, quick-disconnect filter. It's a bag filter, positive gasket seal, restrainer basket, coupling and directional nozzle in one self-contained vessel. The unit even features built-in stops to limit insertion depth into closed head drums.

FSI offers this final stage drum filter in Stainless Steel or Carbon Steel, for applications ranging from chemicals, paints, inks, solvents and resins, to oil, petrochemicals and more viscous products as well.

Features:

- 1-10 GPM flow rate.
- FMC 1½" quick connect female coupling and BUNA-N gaskets come standard; optional 1½" male connector available.
- Popular nylon monofilament (NMO) bag features a molded plastic seal to prevent fluid bypass.
- Filter container made from 304 stainless steel or carbon steel (316 SS on request)

- Overall length of only 9¼".
- Shell, collar, coupling, stop pins and all parts included.
- Units are also available without stop pins.
- Standard 304 stainless steel restrainer basket.
- Positive gasket seal.
- Gaskets are available in the following materials: BUNA-N, Neoprene, Viton.

HOW TO ORDER BAGS

Example: **BNMO10FMC**

Type of Filter:

B = Bag

Material:

NMO = Mesh, Nylon Monofilament

Micron Rating:

NMO = 1,5,10,25,35,55,75,100,125,
150,200,300,400,600,800

Vessel Type:

FMC - 22 Drum Filter

For Vessel, order part no. VB407483N